



Tessera Surface Canopy Option

INSTALLATION INSTRUCTIONS - Surface Canopy Option for use with 3100, 3101, 3103, 3121 and 3921
Applies to Surface Wiring Canopy (-SC1) and Surface Wiring Conduit Feed Canopy (-SC) Options

1. Remove luminaire from carton.
2. Remove (2) flat head screws located on the surface canopy that hold the fixture to mounting plate. Disconnect the blue and red LED leads from the lever nut.
3. Remove the mounting plate with LED driver from surface canopy.
4. Mount the surface canopy on to the wall (3100, 3101, 3103) or ceiling (3121, 3921) surface with holes provided (mounting hardware by others). Ensure that surface canopy is securely attached.
5. Remove conduit plug supplied on surface canopy and thread supply conduit into box (1/2" electrical conduit by others). Thread seal tape may be required. (For conduit feed only)
6. Connect black, green and white leads from the driver to the supply wires located in the surface canopy.
7. Attach mounting plate to surface canopy with screws provided (removed in step 3). Tuck the supply connections and wires carefully in to the surface canopy before attaching the mounting plate. Ensure no wires are pinched.
8. Re-attach the blue and red LED leads to the lever nut. When attaching the housing assembly the lever nut should be flat in order to fit into the wall canopy compartment.
9. Attach the housing assembly to the mounting plate with (2) screws removed in step 2.
10. Energize and test as required.
11. This fixture is supplied with an LED as specified for the project and is self contained.
12. For exterior / wet locations, silicone sealant should be applied to the top and down both sides to exclude water entrance. Sealant between wall or ceiling surface and surface canopy box.